

## **Swing Clear Hinge Installations Instructions**

Remove existing hinges from the door jam and door.

Attach the offset hinge to the door, countersunk holes facing you.

Using the screws provided to affix the hinge to the door frame.

Repeat this step to attach the second or third offset hinge.

Attach the other side of the offset hinge to the door jam (countersunk holes facing you).

Use the screws provided and screw into existing holes.

Repeat this step to attach the second or third offset hinge.

It can be easier to install the offset hinges by pulling the hinge pins and then installing the separated hinge halves to the door and jam.

Set the door in the opening and reinsert the hinge pins.

