


With proper installation, the maximum recommended weight for doors is 200 pounds.

www.stoneharborhardware.com


5

(X 2)




CENTER THE ANTI-JUMP DISCS ON THE TOP EDGE OF THE DOOR. MAKE SURE THE SCREWS ARE ON THE FORWARD EDGE OF THE DOOR. DISCS CAN BE ROTATED OUT OF THE WAY TO INSTALL THE DOOR ON THE TRACK.

6




1 HANG THE DOOR ON THE TRACK. ROTATE THE ANTI-JUMP DISCS BACK SO THEY ARE CENTERED ON THE TOP OF THE DOOR.

7




CHOOSE WHICH FLOOR GUIDE SET YOU WANT TO INSTALL. TO USE THE HIDDEN FLOOR GUIDE, USE A ROUTER TO CUT THE OPENING IN THE BOTTOM OF THE DOOR.




8

INSTALL AND ADJUST THE TRACK END STOPS.



9

(X 4)



INSERT THE PROVIDED PLUGS INTO THE HOLES AT THE END OF THE TRACK.

With proper installation, the maximum recommended weight for doors is 200 pounds.

www.stoneharborhardware.com